

03-92

CUSTOMER	PART NUMBER	REV	CONSTRUCTION	SCHEMATIC DRAWING
Bluepacket	ATS-650			
BOBBIN: BB-EI1903-01				
CORE: LM-EI19-03				
GAP: EI間加一層#1340W TAPE 1作 GAP				
TAPE: 3M#1340W				
ASSEMBLY: 全E全I加GAP 外層3mm TAPE 2TS				
FRAME(CLIP):				BOTTOM VIEW PIN LOCATION
PIN#1 INDICATOR: 凹孔				

TAP WID Mm	TAP LYR	WID	STR	END	CW/CCW	WIR SIZ	COA	TUR	CRE PAG	DEN LSN	SIDE WALL
10	3	W1	2	3	順	0.06	2UEW	1040	厚	密	10mm 雙層1/2
9.2	線	W2	7	5	順	0.06	2UEW	570		密	
10	2	W3	8	6	順	0.06	2UEW	570		密	
		W4									
		W5									
		W6									
		W7									
		W8									

REMARKS

1. 繞 W1 時, BOBBIN PIN#1 朝外
繞 W2, W3 時, BOBBIN PIN#1 朝內

2. 包內層 TAPE 時, SIDE WALL 要貼好. 貼外層 TAPE 時, 將 SIDE WALL 反折包好

3. 內層 TAPE 先貼 2/3 TS. 貼 SIDE WALL 後, 再貼 1/3 TS 或 STS.

PAGE 1	OF 1	REV.
Design Engineer:		
Kevin		

4. 內層引線一定要入 BOBBIN 中間線滿, 否則易 HI-POT 不良.