


USER MANUAL



INSTALLATION

1. CONNECT THE PLUG OF PHONE (RJ11)
TO THE PHONE SIDE OF ATF024
2. CONNECT THE ADSL C/0 LINE TO THE
LINE SIDE OF ATF024