

# USER MANUAL



## INSTALLATION :

1. CONNECT THE PLUG OF PHONE (RJ-11) TO THE PHONE SIDE OF ATF024A
2. CONNECT THE PLUG OF ADSL C/O LINE (RJ-11) TO THE LINE SIDE OF ATF024A