


USER MANUAL



INSTALLATION

1. CONNECT THE PLUG OF PHONE (RJ-11) TO THE PHONE SIDE OF ATF096R
2. CONNECT THE PLUG OF VDSL/ADSL C/O LINE (RJ-11) TO THE LINE SIDE OF ATF096R
3. CONNECT THE PLUG OF VDSL MODEM (RJ-11) TO THE MODEM SIDE OF ATF096R

						Atech[®]		TITLE VDSL POTS SPLITTER	
						Atech Technology Co., Ltd.		DWG. NO.	
						TEL: (02) 2794-6667 FAX: (02) 2794-8004		ATF096R	
RELEASE		08/09	PAIR		SUEDY	UNITS:		SAFETY	
		DATE	BY	CHK	APPD	M/M			
NO:	DESCRIPTION	DATE	BY	CHK	APPD	DATE		SHEET 1 OF 1	
REVISIONS						08/09		DRAW	
								Pair	